

Safety

1. To prevent possible hearing damage, do not listen at high volume levels for long periods.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of battery according to the instruction.
3. Recycle your products

The WEEE logo (shown at right) appears on the product to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by transporting to an appropriate collection point for recycling of such hazardous waste.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

IC Warning:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Notice

This device complies with Part 15 of FCC rules. Operation is subject to the following 2 conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty

Eartec items are warrantied against defects in material and/or factory workmanship for a set period from the date of purchase. Standard repairs due to misuse or wear and tear, as well as replacement parts including but not limited to batteries, padding, USB cable, etc. are excluded. Shipping to Eartec is at customer's expense, Eartec will pay for return ground shipping if the product warranty applies to the repair. Call for details.

Shipping

Prior to returning your headset for warranty or service you must call Eartec for an RA (return authorization) number: 1.800.399.5994.

General Service

All repair work will be performed for the cost of replacement parts and return shipping from the Eartec factory.

Service / Eartec
145 Dean Knauss Drive
Narragansett, RI. 02882

www.eartec.com
1.800.399.5994



The **EPAK**

Communicate in Total Comfort

Full Duplex Wireless



IMPORTANT

E-Pak intercoms include one "MAIN" transceiver.



When this MAIN unit is

turned "ON" all radios in the system will link automatically.

OPERATION

Linking the E-Pak Radios

1. Install charged batteries.
2. Identify MAIN transceiver and press the power button to turn ON.
3. Turn ON all REMOTE radios.
4. Flashing system/power LEDs turn **solid green** indicating radios are linked.



Slide open battery door
Arrow/ contacts first

WIRED HEADSETS

E-Pak will accommodate either wired or wireless headsets. A dual pin wired headset jack is located on the radio chassis.



BATTERY CHARGING

Individual LED Indicators:

Red - Charging

Green - Charged



Charge time appx.
3 hours

PAIRING WIRELESS HEADSETS

Eartec wireless headsets are paired to the E-Pak via the blue programming button.

This blue push button is also a LED that indicates wireless headset.

NOTE: Wireless headsets included with all new systems are already paired to E-Pak.



BLUE LED INDICATIONS

1. Slow Flash Searching for the most recently paired headset
2. Solid Blue E-Pak and wireless headset are connected
3. Rapid Flash Ready to pair with a new wireless headset
4. Blank No wireless headset connected

Slow Flash – E-Pak is searching for the most recently paired headset

- When an E-Pak is turned ON the **blue programming button** will flash slowly for 60 seconds indicating that the radio is searching for the headset to which it has been previously paired.

Solid Blue LED – E-Pak is connected to wireless headset

- When that previously paired headset is turned ON, the E-Pak and headset link automatically and the **blue programming button** turns solid blue.

Rapid Flash or Blank LED – Ready to pair with another wireless headset

- The E-Pak cannot "find" the last paired headset, and/or you wish to pair another wireless headset.
- Press and hold E-Pak **programming button** for three seconds until it begins to flash blue rapidly (search mode).
- Turn ON wireless headset.
- Press and hold the headset's pairing button until it begins flashing red/blue or gives an audible pairing message.
- Headset & E-Pak LEDs should turn solid blue (indicating successful pairing).